

Bulldog Chain Lock Fitting Instructions

Important: You are advised to site the ribbed ground lock tube on a concrete or tarmac site and NOT on loose ground.

1. A hole approximately 200mm deep by 200mm diameter (8" x 8") should be cut into the concrete or tarmac site. The hole can be formed quite quickly if a pneumatic hammer tool is available and these can be hired from most Tool Hire Specialists.
2. A stiff mixture of concrete should be laid in the bottom of the hole and tamped down until it is compact. This provides support for the base of the ribbed ground lock tube.
3. Place the ribbed ground lock tube in the hole ensuring top face is flush with the ground level, and the 1" diameter clearance hole is at the top.
4. Fill around outside of lock tube with concrete.
5. An hour or so later trowel off the surface to match the rest of the floor surface.
6. The concrete should then be left to set for at least 2 days although exact setting time varies according to the weather.
7. Once concrete is thoroughly set you can insert the lock bolt and the protective plastic cap.
8. The Bulldog chain can also be used with the lock bolt and cup as shown.
9. Caring for your Bulldog Locking Bolt. To ensure long life DO NOT allow dirt to enter the locking mechanism.



TIP. Where possible, position the ribbed tube socket in a place where it would be difficult for a would be thief to attack e.g. in case of motorcycles between the bike and a wall for example.

We have taken every care in the design and manufacture of this security device and we believe that it is an effective deterrent. However we cannot guarantee that it will resist the efforts of the most determined thief, and as such we do not accept liability for loss or damage caused by theft, vandalism or other illegal activity against property to which this device is fitted.

Lock Lubrication.

IMPORTANT - To ensure free movement of the lock, spray outside of lock body with WD40 (or equivalent) minimum every four months.

Key Security. Enter your key number here:

IMPORTANT - Your Bulldog product is supplied with two keys. Make a note of your personal key number in the space provided above and **keep it in a safe place**. Should you lose your keys, replacements can only be obtained from the manufacturer through your dealer.